

SKYPE DESKTOP PHONE

MAKE SKYPE CALLS TO ANYWHERE IN THE WORLD WITHOUT A COMPUTER

S0-10

NO COMPUTER REQUIRED

IPEVO S0-10 is a Skype-embedded Internet phone that enables Internet calls without using a computer. An always on, dedicated device, S0-10 makes Skype calls as easy as using a regular telephone.

Always on, always available

S0-10 is developed to allow users to use Skype with the familiarity of a regular desktop phone. It is always on and always available for Skype-to-Skype, Skypeln, SkypeOut and Skype Voicemail.

Simple set-up: plug in, log in, and call

S0-10 works wherever a broadband Internet connection is available. Setting up is as easy as plugging in the network cable, log in to your Skype account, and just pick up to make a call!

Friendly operation, with familiarity and functionality of a traditional telephone

The user-friendly Skype interface is displayed on 2.4" TFT color LCD, making operating the functions simple and easy. Additional convenient features include a built-in speakerphone and 3 quick-dial keys.

Key Features

- No computer required
- Simple plug-and-connect to set up
- 2.4" TFT color LCD display with adjustable viewing angle
- Excellent voice quality with echo cancellation
- Support Skype-to-Skype, SkypeOut, Skypeln and Skype Voicemail
- One click speakerphone function for hands-free talks
- Memory keys for speed dials
- LED for indications of power on/off, missed call, message, mute and speakerphone mode



CHIP Magazine, Germany
Product of the Month, October 2007



IPEVO creates Internet devices that expand and enhance the overall Experience over the Internet. Renowned for its iconic line of best-selling VoIP and Skype hardware, IPEVO has established a reputation for innovating award-winning designs and affordable products to help make the Internet a better place for what matters most - connecting, communicating, and sharing with the world around us.

PACKAGE CONTENT
<ul style="list-style-type: none"> • IPEVO S0-10 Skype Desktop Phone • Switching power adaptor (100-240V 50-60Hz) • CAT5 Ethernet cable • Quick Guide
DIMENSION / WEIGHT
<ul style="list-style-type: none"> • Size: 19.3x16.8x6.2cm (LxWxH) • Weight: 600g
COLOR
<ul style="list-style-type: none"> • Black body with white handset
CONTROL BUTTON
<ul style="list-style-type: none"> • Dial / Answer • Redial • Mute on / off • Speakerphone on / off • Volume • Status indication • Full color LCD display • Function command • Main menu navigation key • Cancel / Hang up • Speed dial keys
LED INDICATION
<ul style="list-style-type: none"> • Blue Power LED: Power on / off • Green Active LED to indicate: Incoming calls Unread voicemails Missed calls Call established

NETWORK PROTOCOLS
<ul style="list-style-type: none"> • Static IP, DHCP, PPPoE • TCP/UDP/IPV4 • DNS
AUDIO PERFORMANCE
<ul style="list-style-type: none"> • Voice codecs: G.729AB • Voice sampling rate: 8KHz • Communication: Full Duplex • Echo cancellation in speakerphone mode
HARDWARE DESCRIPTIONS
<ul style="list-style-type: none"> • USB interface 1.1 reserved for extension modules • Audio • 8Ω 2W Speaker • Network interface • Fast Ethernet 100Mbps • Auto crossover detection • Auto rate detection • Integrated 2-port fast Ethernet switch (2xRJ-45)
ELECTRICAL SPECIFICATIONS
<ul style="list-style-type: none"> • Operating Voltage: 5VDC 2000mA
SYSTEM REQUIREMENTS
<ul style="list-style-type: none"> • Broadband Internet connection (DSL, Cable Modem..., etc) • Broadband modem, router or gateway
REGULATORY COMPLIANCE
<ul style="list-style-type: none"> • FCC • CE • VCCI • RoHs



WiFi NETWORK ADAPTER

For IPEVO S0-10 Skype Desktop Phone

- Upgrade S0-10 to access wifi connection
- Adjustable antenna to maximize wifi reception
- High speed wireless transmission. Clear and stable sound quality

PACKAGE CONTENT	
<ul style="list-style-type: none"> • IPEVO WiFi Network Adapter • USB cable • CD-ROM containing installation guide and S0-10 upgraded firmware • Quick Guide 	
DIMENSION / WEIGHT	COLOR
<ul style="list-style-type: none"> • Size: 57.15(L)x76.2(W)x12.7(D)mm • Weight: 30g 	<ul style="list-style-type: none"> • Black
LED INDICATION	
<p>WiFi activity LED: Green Blinks when there is activity on the wifi connection</p> <p>USB activity LED: Steady green when the USB connection is active</p>	
WiFi PROTOCOLS SUPPORT	HARDWARE DESCRIPTIONS
<ul style="list-style-type: none"> • IEEE 802.11b/g • WEP64/WEP128 • WPA-PSK/WPA2-PSK/TKIP/CCMP 	<ul style="list-style-type: none"> • USB 1.1/2.0
SYSTEM REQUIREMENTS	
<ul style="list-style-type: none"> • S0-10 Skype Desktop Phone 	
REGULATORY COMPLIANCE	
<ul style="list-style-type: none"> • FCC class B • CE class B • NCC • RoHs 	